

Spider Hill Prop Works BK-1 or KIT-2

(Single Spine Version – approx. 6 feet tall)

Parts Included:

| □ (9) SJ-1 Spider Joints |
|--|
| □ (2) UMB-1 Universal Mounting Bases |
| ☐ (1) 1" to ½" slip fit schedule 40 reducer bushing |
| ☐ (1) 4" piece of ½" schedule 40 PVC pipe |
| ☐ (1) 1" slip fit schedule 40 PVC cross fitting |
| ☐ (1) 1" slip fit schedule 40 PVC Tee fitting |
| ☐ (11) Feet of 1" schedule 40 PVC pipe (included in BK-1 only) |
| □ (24) #10 x 5/8" Self Drilling Screws |
| NULL CONTROL OF STATE |
| <u>Materials Needed:</u> |
| ☐ Foam wig head (needed for both kits) |
| ☐ (11) Feet of 1" Schedule 40 PVC pipe (required for KIT-2 only) |
| ☐ Plywood base approx. 24" x 15" x 3/4" (needed for both kits) |
| C. t. Lint. |
| <u>Cut List:</u> |
| □ A) Neck: (1) 4" piece of ½" pipe |
| □ B) Spine (Articulated): (2) 7 1/8" pieces of 1" pipe |
| □ B) Spine (Non-Articulated): (1) 19" piece of 1" pipe |
| □ C) Shoulders: (2) 6" pieces of 1" pipe |
| □ D) Upper Arms: (2) 8 ½" pieces of 1" pipe |
| ☐ E) Forearms: (2) 9 ¼" pieces of 1" pipe |
| ☐ F) Hips: (2) 2 ¼" pieces of 1" pipe |
| ☐ G) Femurs: (2) 12" pieces of 1" pipe |
| ☐ H) Tibias: (2) 18" pieces of 1" pipe |

Helpful Hints:

Do not over tighten the self-drilling screws! Start with a drill, complete final tightening by hand.

Place the screws in the middle of the SJ-1 slots to allow the most adjustment in either direction.

Heavier loads may require a second screw to prevent slippage.

www.spiderhillpropworks.com