



Spider Hill Prop Works
Grave Grabber Kit
www.spiderhillpropworks.com

Spider Hill Prop Works Grave Grabber Kit

Parts Needed:

- (4) SJ-1 Spider Joints**
- (1) UMB-1 Universal Mounting Base**
- (1) 1" to 1/2" slip fit schedule 40 reducer bushing**
- (1) 4" piece of 1/2" schedule 40 PVC pipe**
- (1) 1" slip fit schedule 40 PVC Cross fittings**
- (5) feet of 1" schedule 40 PVC pipe**
- (1) Foam wig head**
- (12-16) #10 x 1/2" self drilling Phillips pan head screws**
- (1) 16" long x 12" wide x 1/2" thick wood base (plywood or MDF)**

Cut List:

- A) Neck: (1) 4" piece of 1/2" pipe**
- B) Spine: (1) 14" piece of 1" pipe**
- C) Shoulders: (2) 6" pieces of 1" pipe**
- D) Upper Arms: (2) 8 1/2" pieces of 1" pipe**
- E) Forearms: (2) 8" pieces of 1" pipe**

Helpful Hints:

Do not over tighten the self-drilling screws! Start with a drill, complete final tightening by hand.

Place the screws in the middle of the SJ-1 slots to allow the most adjustment in either direction.

Heavier loads may require a second screw to prevent slippage.