

# SPIDER HILL PROP WORKS

## HEAD LIFTING MECHANISM (Part# HLM-1)

It is recommended to keep the load to be lifted under 5lbs.

Mounting the unit along the edge of a board (such as a 2x4) will provide the best support for the mechanism.

The lift rod can be trimmed as needed. Make sure it is measured at its lowest point so you do not cut too much off!

The lift rod has the same OD as 1/2 Schedule 40 PVC and can be used with standard pipe fittings. Most foam wig heads should fit snugly on the lift rod.

If the unit will be used outside, it is ok to spray it down with silicone lubricant for added protection from moisture. **DO NOT USE PETROLEUM BASED LUBRICANTS!**

The lift rod/bearing does not need to be lubricated.



Use Caution when working with electricity!



Do not force the motor to turn while powered off or damage may occur!

Do not get the motor or power supply wet! if you are going to use the unit outside you must provide it with protection from the elements.

Take care to make sure no prop hair or materials get tangled in the mechanism.

If you need assistance, please contact us at [info@spiderhillpropworks.com](mailto:info@spiderhillpropworks.com)

**2019 Spider Hill Prop Works**

**[www.spiderhillpropworks.com](http://www.spiderhillpropworks.com)**

**5/21/2019**

One example for mounting behind a wall or fence.

